

# #CPI

## Overcurrent Protection Instructions Manual

## License agreement for Software Embedded in Equipment

### ZIV APLICACIONES Y TECNOLOGÍA, S.L. End-User Software License Agreement

**THE EQUIPMENT YOU HAVE PURCHASED INCLUDES EMBEDDED SOFTWARE PROGRAM(S). THE PROGRAM IS COPYRIGHTED AND IS BEING LICENSED TO YOU (NOT SOLD) FOR USE WITH THE EQUIPMENT.**

**THIS IS A LEGAL AGREEMENT BETWEEN US (AS “LICENSEE”) AND ZIV APLICACIONES Y TECNOLOGIA, S.L. (AS “LICENSOR”) FOR THE SOFTWARE PROGRAM INCLUDED WITH THE EQUIPMENT. PLEASE READ THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT CAREFULLY BEFORE USING THE EQUIPMENT.**

**IF YOU INSTALL OR USE THE EQUIPMENT, YOU ARE ACCEPTING AND AGREEING TO THE TERMS OF THIS LICENSE AGREEMENT. IF YOU ARE NOT WILLING TO BE BOUND BY THE TERMS OF THIS LICENSE AGREEMENT, YOU SHOULD PROMPTLY RETURN THE EQUIPMENT UNUSED TO YOUR SELLER, AND YOU WILL RECEIVE A REFUND OF YOUR MONEY.**

#### Terms and Conditions of License

1. **License Grant.** Licensor hereby grants to you, and your accept, a nonexclusive and non-transferable license to use the embedded programs and the accompanying documentation, if any (collectively referred to as the “Software”), only as authorized in this License Agreement.
2. **Restrictions.** You may not (a) use, copy, modify or transfer the Software except as expressly provided in this or another Agreement with Licensor, (b) reverse engineer, decompile or disassemble or separate the components of the Software, or (c) rent, sell or lease the Software or make the Software available to others to do any of the foregoing.
3. **No Assignment.** This License is intended for your exclusive use with the purchased equipment. You agree that you will not assign, sublicense, transfer, pledge, lease, rent or share your rights under this License Agreement.
4. **Licensor’s Rights.** You acknowledge and agree that the Software is the proprietary product of Licensor protected under U.S. copyright law and international treaties.. You further acknowledge and agree that all right, title and interest in and to the Software, including associated intellectual property rights, are and shall remain with Licensor. This License Agreement does not convey to you an ownership interest in or to the Software, but only a limited right of use revocable in accordance with the terms of this License Agreement.
5. **Confidentiality.** The Software is confidential and no details or information relating to the same shall be disclosed to any third party without the prior written consent of Licensor. For the purposes of this clause, sub-contract staff, employed or retained by the Licensee to perform computer systems development work, shall not be deemed to be third parties provided such staff are subject to the disclosure restrictions set forth above. In no event, except with a prior written authorization duly signed by an officer of Licensor, may you disclose any such confidential information, even for subcontracted jobs, to persons or entities that may be considered to be direct competitors of Licensor.

6. **Term.** The License Agreement is effective upon delivery of the equipment to you and shall continue until terminated. You may terminate this License Agreement at any time by returning the equipment to Licensor, or by destroying the equipment. Licensor may terminate this License Agreement upon your breach of any term hereof. Upon such termination by Licensor, you agree to return the equipment to Licensor.
7. **Warranty and Disclaimer.** Licensor warrants, for your benefit only, that the Software, when and as delivered to you, will conform to the specifications described in the instruction manuals for the equipment purchased, or any specifications agreed to in writing by Licensor with a particular customer. This warranty does not cover any minor errors or deviations from the specifications that do not affect the proper functioning of the equipment. **EXCEPT FOR THE WARRANTIES SET FORTH ABOVE, THE SOFTWARE IS LICENSED “AS IS”, AND LICENSOR DISCLAIMS ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**
8. **Licensee’s Remedy.** Your sole and exclusive remedy for any breach of Licensor’s warranty shall be the repair or replacement, at Licensor’s sole option, of any Software that does not conform to stated specifications. Licensor shall not be responsible for any failure arising from inadequate or improper use of the Software.
9. **Limitation of Liability.** Licensor’s cumulative liability to you or any other party for any loss or damages resulting from any claims, demands, or actions arising out of or relating to this Agreement shall not exceed the purchase price paid to Licensor for the equipment. In no event shall Licensor be liable for any indirect, incidental, consequential, special, or exemplary damages or lost profits, even if Licensor has been advised of the possibility of such damages.
10. **Trademark.** All ZIV trademarks (including ZIVERCOM, ZIVERLOG and ZIVERSYS) are common law trademarks of Licensor. No right, license or interest to such trademarks is granted hereunder, and you agree that no such right, license or interest shall be asserted by you with respect to such trademark.
11. **Licensee’s Indemnity.** You shall defend, indemnify and hold Licensor harmless against any loss or damage of any kind arising from a breach by you of this License Agreement, or any use or misuse of the Software by you or your employees, agents or representatives, and from any other of your conduct or from any claim or action by any of your customers in connection with the Software or this License Agreement.
12. **Governing Law.** This License Agreement shall be construed and governed in accordance with the internal laws of the State of Illinois, U.S.A.
13. **No Waiver.** The failure of either party to enforce any rights granted hereunder or to take action against the other party in the event of any breach hereunder shall not be deemed a waiver by that party as to subsequent enforcement of rights or subsequent actions in the event of future breaches.
14. **Entire Agreement.** This License Agreement is the entire agreement between you and Licensor with respect to the use of the software and supersedes all prior understandings or agreements between the parties. This License Agreement may be amended only by a writing signed by an officer of Licensor.

**ZIV Aplicaciones y Tecnología, S.L.**  
**Parque Tecnológico, 2089**  
**48016 Zamudio (Vizcaya)**  
**48080 Bilbao**  
**Spain**

# Table of Contents



<b>Chapter 1. Description</b>	
1.1	Functions ..... 1-2
1.1.1	Phase Overcurrent Protection (3x50/51). #CPI-A Models..... 1-2
1.1.2	Phase and Ground Overcurrent Protection (3x50/51 + 50N/51N). #CPI-B Models..... 1-2
1.1.3	Ground Overcurrent Protection (50N/51N). #CPI-C Models ..... 1-3
1.2	Common Functions to all Models ..... 1-3
1.3	Model Selection ..... 1-4
<b>Chapter 2. Technical Data</b>	
2.1	Power Supply Voltage ..... 2-2
2.2	Power Supply Burden ..... 2-2
2.3	Current Analog Inputs..... 2-2
2.4	Measurement Accuracy ..... 2-2
2.5	Time Measurement Accuracy ..... 2-2
2.6	Repeatability ..... 2-3
2.7	Status Contact Inputs ..... 2-3
2.8	Trip Outputs and AUX-1 ..... 2-3
2.9	Auxiliary Contact Outputs (AUX-2 and AUX-3) ..... 2-4
2.10	Communications Link ..... 2-4
<b>Chapter 3. Standards and Type Test</b>	
3.1	Insulation..... 3-2
3.2	Electromagnetic Compatibility ..... 3-2
3.3	Environmental Test..... 3-3
3.4	Power Supply..... 3-3
3.5	Mechanical Test..... 3-3
<b>Chapter 4. Physical Architecture</b>	
4.1	General ..... 4-2
4.2	Dimensions ..... 4-3
4.3	Connection Elements..... 4-4
4.3.1	Terminal Connectors ..... 4-4
4.3.2	Removing Printed Circuit Boards (Non Self-Shorting) ..... 4-4
4.3.3	Internal Wiring..... 4-4
<b>Chapter 5. Settings</b>	
5.1	Configuration Settings ..... 5-2
5.2	General Settings ..... 5-2
5.3	Protection Elements Settings ..... 5-3
5.4	Digital Inputs, Auxiliary Outputs and LED Targets ..... 5-4



<b>Chapter 6. Description of Operation</b>		
6.1	Overcurrent Units .....	6-2
6.1.1	Time Elements .....	6-2
6.1.1.a	Time/Current Characteristics .....	6-3
6.1.2	Overcurrent Unit Block Diagram .....	6-6
6.1.3	Instantaneous Elements .....	6-6
6.2	General Settings .....	6-7
6.2.1	Transformer Ratio .....	6-7
6.2.2	Event Masking.....	6-7
6.3	Event Recording .....	6-7
6.4	Contact Inputs, Outputs & LED Targets .....	6-10
6.4.1	Status Contact Inputs.....	6-10
6.4.2	Auxiliary Contact and Trip Outputs .....	6-11
6.4.3	LED Targets.....	6-13
6.5	Communications .....	6-14
6.5.1	Communications Settings .....	6-14
6.5.2	Communications Types .....	6-14
6.5.3	Communicating with the Unit.....	6-14
<b>Chapter 7. Alphanumeric Display and Keypad</b>		
7.1	Alphanumeric Display and Keypad .....	7-2
7.2	Keys, Functions and Operation Modes.....	7-2
7.3	Screen Sequence using a Single Key .....	7-4
7.4	Screen Sequence using the Complete Keypad.....	7-7
<b>Chapter 8. Receiving Tests</b>		
8.1	General .....	8-2
8.1.1	Accuracy .....	8-2
8.2	Preliminary Inspection.....	8-3
8.3	Insulation Test.....	8-3
8.4	Current Measuring Test .....	8-4
8.5	Phase and Ground Units Test.....	8-4
8.6	Contact Inputs, Auxiliary Outputs and LED Targets Test .....	8-5
8.7	Communication Test.....	8-5
8.8	Installation .....	8-6
8.8.1	Location.....	8-6
8.8.2	Connection .....	8-6



---

<b>A.</b>	<b>Protection Communications Protocol PROCOME 3.0</b>	
A.1	Settings .....	A-2
A.1.1	Configuration Settings .....	A-2
A.2	Description of Operation .....	A-2
A.2.1	Event Record .....	A-2
A.2.2	Inputs .....	A-2
A.2.3	Communicating with the Unit.....	A-2
A.3	Alphanumeric Keypad and Display.....	A-3
A.3.1	Communications .....	A-3
A.3.2	Accessing the Information .....	A-3
<b>B.</b>	<b>DNP 3.0 Communications Protocol</b>	
B.1	Physical Architecture .....	B-2
B.2	Settings .....	B-3
B.3	Description of Operation .....	B-3
B.3.1	DNP 3.0 Protocol .....	B-3
B.3.2	Communications .....	B-4
B.3.2.a	Communication with the Equipment .....	B-4
B.4	Alphanumeric Keypad and Display.....	B-4
B.4.1	DNP 3.0 Settings Menu (Zivercom®) .....	B-4
<b>C.</b>	<b>MODBUS RTU Documentation. Address Map</b>	
C.1	Preliminary Information.....	C-2
C.2	Reading of Outputs (Read Coil Status) .....	C-2
C.3	Reading of Inputs (Read Input Status) .....	C-3
C.4	Reading of Metering Register (Read Input Registers) .....	C-3
C.5	Commands (Force Single Coil) .....	C-4
<b>D.</b>	<b>Schemes and Drawings</b>	
<b>E.</b>	<b>List of Illustrations and Tables</b>	
E.1	List of Figures .....	E-2
E.2	List of Tables .....	E-2
<b>F.</b>	<b>Warranty</b>	

---



# 1. Description



---

1.1	Functions .....	1-2
1.1.1	Phase Overcurrent Protection (3x50/51). #CPI-A Models.....	1-2
1.1.2	Phase and Ground Overcurrent Protection (3x50/51 + 50N/51N). #CPI-B Models ...	1-2
1.1.3	Ground Overcurrent Protection (50N/51N). #CPI-C Models .....	1-3
1.2	Common Functions to all Models .....	1-3
1.3	Model Selection .....	1-4

---



The **#CPI** protection relay is designed for overcurrent protection in electrical networks using state-of-the-art digital technology.

**#CPI** terminals are designed for application on circuits (feeders, transformers, motors, etc...) where overcurrent protection for phase-to-phase faults, and ground faults is required.

For isolated ground systems where a high sensitivity ground protection is required, the application of directional overcurrent (67N<sub>I</sub>) is recommended.

Note: This instruction manual covers the models **#CPI-A**, **#CPI-B**, and **#CPI-C**. Other **CPI** models have separate instruction manuals.

## 1.1 Functions

Functions included in the terminals are model dependent as listed in Section 1.3. This instruction manual covers both series (**3CPI** and **8CPI**), since their functionality is identical.

### 1.1.1 Phase Overcurrent Protection (3x50/51). #CPI-A Models

Includes three phase overcurrent protection units. The three phases share the same settings. Each phase unit includes two independent protection elements; one time delayed element, and one instantaneous element with a definite time setting.

The time delay elements are provided with five characteristics: **Inverse**, **Very Inverse**, **Extremely Inverse**, **Definite Time**, and **User** defined. Time delayed and instantaneous elements can be disabled via settings. **#CPI-A** models also include information on pickup and trip for each phase instantaneous and time delayed elements.

### 1.1.2 Phase and Ground Overcurrent Protection (3x50/51 + 50N/51N). #CPI-B Models

Includes three phase and ground overcurrent protection units. The three phases share the same settings while the ground unit has independent settings. Each unit includes two independent protection elements; one time delayed element, and one instantaneous element with a definite time setting.

The time delayed elements are provided with five characteristics: **Inverse**, **Very Inverse**, **Extremely Inverse**, **Definite Time**, and **User** defined. Time delay and instantaneous elements can be disabled via settings. **#CPI-B** models also include information on pickup and trip for each phase and ground instantaneous and time delayed elements.



### 1.1.3 Ground Overcurrent Protection (50N/51N). #CPI-C Models

Includes ground overcurrent protection unit. The ground unit includes two independent protection elements; one time delayed element, and one instantaneous element with a definite time setting.

The time delayed element is provided with five characteristics: **Inverse**, **Very Inverse**, **Extremely Inverse**, **Definite Time**, and **User** defined. Time delayed and instantaneous elements can be disabled via setting. #CPI-C models also include information on pickup and trip for both the instantaneous and the time delayed elements.

**Note:** ground units of the #CPI-\*\*\*-\*\*\*010\*\* models don't trip.

## 1.2 Common Functions to all Models

- **LED Targets**

Terminal unit front panel indication consists of eight LED's. Seven of the LED's are user definable. The eighth LED is assigned to indicate the terminal unit is "**Ready**" (powered up, self-test OK). A list of available LED signals is defined in Chapter 6.

- **Status Contact Inputs**

The terminal unit has two status contact inputs, both are configurable. A list of available inputs is defined in Chapter 6.

- **Auxiliary Contact Outputs**

There are three auxiliary contact outputs, two of which are configurable. Auxiliary Output **AUX-3**, which corresponds to terminal unit "**In Service**" (powered up, self-test OK), is not programmable. A list of available outputs is defined in Chapter 6.

- **Local Information (display)**

Display of:

- Events:
  - Last relay operation (tripped element)
  - Status contact input status
  - Auxiliary contact output status
  - Protection element status
- Metering:
  - Current

- **Self-Test Program**

A continuously running diagnostic self-test program verifies the correct operation of the terminal unit and alerts the user of potential problems.



### 1.3 Model Selection

	CPI											
1	2	3	4	5	6	7	8	9	10	11	12	
1	<b>Selection</b>		3 Vertical Format				8 Horizontal Format					
2	<b>Functions</b>											
	A 3x50/51											
	B 3x50/51 + 50N/51N											
	C 50N/51N											
3	<b>Rated Current</b>											
	1 If = 5A / In = 1A			4 If = 5A / In = 1A			5 If = 1A / In = 1A					
	2 If = 5A / In = 5A											
	3 If = 5A / In = 20mA											
4	<b>Options</b>											
	B Basic Model			G [In > 0.2 - 2.4A; In >> 0.1 - 30A]								
	E [In > 0.1 - 1.2A; In >> 0.1 - 30A]											
5	<b>Supply Rated Voltage</b>											
	Power Supply			Digital Inputs			Power Supply			Digital Inputs		
	1 24 - 48 Vdc			24 - 48 Vdc			3 220 - 250 Vdc			48 - 250 Vdc		
	2 110 - 125 Vdc			24 - 125 Vdc			4 220 Vac			220 Vac		
6	<b>Frequency / Language</b>											
	0 50 Hz / Spanish			E 60 Hz / Portuguese								
	2 60 Hz / English			G 50 Hz / French								
	A 50 Hz / English			J 50 Hz / Portuguese								
	C 60 Hz / Spanish											
7	<b>Communications</b>											
	1 RS232 + RS232			4 RS232 + Glass FO (ST)								
	2 RS232 + Plastic FO 1mm			5 RS232 + RS485								
	3 RS232 + Glass FO (SMA)											
8	0 Standard			1 RS232 Remote (only if COMMUNICATIONS option= 1)								
9	<b>Special Models</b>											
	00 Basic Model			15 Optional Ground Range: (0.1-1.2) x In								
	03 Special DIs [Activation Ranges + Detection Times]			20 IN>: (0.01-0.5 x In) ; IN>>: (0.01-6 x In)								
	04 Special DIs [Activation Ranges]			40 IN>: 1-20A ; IN>>: 0.5-150A								
	10 Phase Trip (*)			If>: 1-20A ; If>>: 0.5-150A								
10	<b>Enclosure</b>											
	D 6U x 1/7 of 19" Rack			V 6U x 1 19" Rack								
11	<b>Communications Protocol</b>											
	A Prot. NO PROCOME + Without Ctrl.			E Prot. NO PROCOME + Ctrl. DNP3 and PROCOME								
	B Prot. NO PROCOME + Ctrl. PROCOME			F Prot. NO PROCOME + Ctrl. MODBUS and PROCOME								

• **Functions**

<b>50</b>	Phase instantaneous Overcurrent
<b>51</b>	Phase Time Overcurrent (Inverse / Fixed)
<b>50N</b>	Ground Instantaneous Overcurrent
<b>51N</b>	Ground Time Overcurrent (Inverse / Fixed)

## 2. Technical Data



---

2.1	Power Supply Voltage .....	2-2
2.2	Power Supply Burden .....	2-2
2.3	Current Analog Inputs .....	2-2
2.4	Measurement Accuracy .....	2-2
2.5	Time Measurement Accuracy .....	2-2
2.6	Repeatability .....	2-3
2.7	Status Contact Inputs .....	2-3
2.8	Trip Outputs and AUX-1 .....	2-3
2.9	Auxiliary Contact Outputs (AUX-2 and AUX-3) .....	2-4
2.10	Communications Link.....	2-4

---



## 2.1 Power Supply Voltage

Selectable range depending on model:

**24-48 Vdc ( $\pm 20\%$ )**  
**110-125 Vdc ( $\pm 20\%$ )**  
**220-250 Vdc ( $\pm 20\%$ )**  
**220 Vac ( $\pm 20\%$ )**

Note: In case of power supply failure, a maximum interruption of 100 ms is allowed for 110Vdc input.

## 2.2 Power Supply Burden

Quiescent	<b>7 W</b>
Maximum	<b>20 W</b>

## 2.3 Current Analog Inputs

Rated Value	<b>In = 5 A</b> (phase & ground) <b>In = 1 A</b> (phase & ground) <b>In = 0.020 A</b> (special ground)
Thermal Withstand Capability	<b>4 In</b> (continuously) <b>50 In</b> (for 3 s) <b>100 In</b> (for 1 s)
Dynamic Limit (Dynamic Load Capacity)	<b>240 In</b>
Current Circuit Burden	<b>In = 5 A &lt; 0.2 VA</b> <b>In = 1 A &lt; 0.05 VA</b> <b>In = 0.020 A &lt; 0.002 VA</b>

## 2.4 Measurement Accuracy

Internal Measure Accuracy	<b>&lt; 5 %</b>
Display Measure Accuracy	<b>&lt; 5 % or 20mA</b> (whichever is greater)

## 2.5 Time Measurement Accuracy

Definite and Inverse Time Characteristic (IEC 255)	<b>E = 5 % or 25 ms</b> (whichever is greater)
--	---



## 2.6 Repeatability

Operating Time	2 % or 25 ms (whichever is greater)
----------------	-------------------------------------

## 2.7 Status Contact Inputs

Two electrically separate, user programmable status contact inputs.

Status Contact Input Voltage Range (selectable range depending on model)	24 - 48 Vdc $\pm 20\%$ 24 - 125 Vdc $\pm 20\%$ 48 - 250 Vdc $\pm 20\%$ 220 Vac $\pm 20\%$
Current Drain	< 5 mA

### #CPI-\*\*\*-\*\*\*003\*\* Model

Status Contact Input Voltage Range	30 - 48 Vdc $\pm 20\%$ 70 - 125 Vdc $\pm 20\%$ 120 - 220 Vdc $\pm 20\%$
Current Drain	48 Vcc $\rightarrow$ 10.4 mA 125 Vcc $\rightarrow$ 6.4 mA 220 Vcc $\rightarrow$ 4.5 mA

## 2.8 Trip Outputs and AUX-1

Two trip contacts internally configurable as NO or NC.

**AUX-1** Form C switch (SPDT) internally configurable as NO and/or NC.

I DC maximum limit (with resistive load)	30 A (1 s)
I DC continuous service (with resistive load)	8 A
I short duration	10A (max. with a duty cycle of 10%)
Close	2500 W
Breaking capability (with resistive load)	150 W - max. 8 A - (48 Vdc) 55 W (80 Vdc - 250 Vdc) 1250 VA
Break (L/R = 0.04 s)	120 W at 125 Vdc
Switching voltage	250 Vdc
Momentary close time trip contacts remain closed	100 ms



## 2.9 Auxiliary Contact Outputs (AUX-2 and AUX-3)

Electrically separate Form C (SPDT) auxiliary contact outputs NO or NC.

I DC maximum limit (with resistive load)	<b>5 A</b> (30 s)
I DC continuous service (with resistive load)	<b>3 A</b>
I short duration	<b>8A</b> (max. with a duty cycle of 10%)
Close	<b>2000 W</b>
Breaking capability (with resistive load)	<b>75 W</b> - max. 3 A - (48 Vdc) <b>40 W</b> (80 Vdc - 250 Vdc) <b>1000 VA</b>
Break (L/R = 0.04 s)	<b>20 W</b> at 125 Vdc
Switching voltage	<b>250 Vdc</b>

## 2.10 Communications Link

### Glass Fiber Optics

Type	<b>Multimode</b>
Wavelength	<b>820 nm</b>
Connector	<b>ST</b>
Transmitter Minimum Power:	
50/125 Fiber	<b>- 20 dBm</b>
62.5/125 Fiber	<b>- 17 dBm</b>
100/140 Fiber	<b>- 7 dBm</b>
Receiver Sensitivity	<b>- 25.4 dBm</b>

### Plastic Fiber Optics (1 mm)

Wavelength	<b>660 nm</b>
Transmitter Minimum Power	<b>- 16 dBm</b>
Receiver Sensitivity	<b>- 39 dBm</b>

### RS232C Port Signals

Terminal unit DB-9 (9-pin) connectors	<b>Pin 5 - GND</b> <b>Pin 2 - RXD</b> <b>Pin 3 - TXD</b>
---------------------------------------	--

# 3. Standards and Type Test



---

3.1	Insulation.....	3-2
3.2	Electromagnetic Compatibility .....	3-2
3.3	Environmental Test.....	3-3
3.4	Power Supply.....	3-3
3.5	Mechanical Test.....	3-3

---



The equipment satisfies the requirements of IEC-255 (EN 21-136) at the maximum class for the values indicated below.

### 3.1 Insulation

<b>Insulation Test (Dielectric Strength)</b>	<i>IEC-60255-5</i>
Between all circuit terminals and ground	<b>2 kV, 50 Hz</b> , for 1 min
Between all circuit terminals	<b>2 kV, 50 Hz</b> , for 1min
<b>Voltage Impulse Test</b>	<i>IEC-60255-5</i>
Common mode (analog inputs, DIs, AOs and PS)	<b>5 kV; 1.2/50 <math>\mu</math>s; 0.5 J</b>

### 3.2 Electromagnetic Compatibility

<b>1 MHz Burst Test</b>	<i>IEC-60255-22-1 Class III</i>
Common mode	<b>2.5kV</b>
Differential mode	<b>2.5kV</b>
<b>Fast Transient Disturbance Test</b>	<i>IEC-60255-22-4 Class IV</i> <i>(IEC 61000-4-4)</i>
	<b>4 kV <math>\pm</math>10 %</b>
<b>Radiated Electromagnetic Field Disturbance</b>	<i>IEC 61000-4-3 Class III</i>
Amplitude modulated	<b>10 V/m</b>
Pulse modulated	<b>10 V/m</b>
<b>Conducted Electromagnetic Field Disturbance</b>	<i>IEC 61000-4-6 Class III</i>
Amplitude modulated	<b>10 V</b>
<b>Electrostatic Discharge</b>	<i>IEC 60255-22-2 Class IV</i> <i>(IEC 61000-4-2)</i>
On contacts	<b><math>\pm</math>8 kV <math>\pm</math>10 %</b>

<b>Radio Frequency Emissivity</b>	<i>EN55022 (Radiated)</i> <i>EN55011 (Conducted)</i>
-----------------------------------	---



### 3.3 Environmental Test

<b>Temperature</b> Operating range Storage range Humidity	<i>IEC 60255-6</i> From <b>-10° C</b> to <b>+ 55° C</b> From <b>-25° C</b> to <b>+ 70° C</b> <b>95 %</b> (non-condensing)
--	--

### 3.4 Power Supply

<b>Power Supply Interference and Ripple</b>	<i>IEC 60255-11</i> <b>&lt; 20 %</b>
---	---

### 3.5 Mechanical Test

<b>Vibration (sinusoidal)</b> <b>Mechanical Shock and Bump Test</b>	<i>IEC-60255-21-1 Class I</i> <i>IEC-60255-21-2 Class I</i>
--	--

The models comply with the EEC 89/336 standard of electromagnetic compatibility.



# 4. Physical Architecture



---

4.1	General .....	4-2
4.2	Dimensions .....	4-3
4.3	Connection Elements.....	4-4
4.3.1	Terminal Connectors.....	4-4
4.3.2	Removing Printed Circuit Boards (Non Self-Shorting).....	4-4
4.3.3	Internal Wiring.....	4-4

---



## 4.1 General

#CPI protection terminals consist of a circuit board with the following functions:

- Power Supply
- Central Processing Unit
- Analog Input Transformers
- Contact Inputs and Outputs

Depending on the terminal settings, contact inputs / outputs may be used or remain as spare signals.

Figures 4.1 and 4.2 show terminal unit front panels for **3CPI** series and **8CPI** series respectively. Dimensions of the front panels are specified at the end of this instruction manual.

Keypad, alphanumeric display, LED targets, and local communications port are located on the front panel.

The rear panel contains terminal connectors as shown in Figures 4.3 and 4.4. There are two terminal connector groups, one corresponds to transformer secondary analog inputs (from 1 to 10 terminal connectors), and the other corresponds to power supply input and contact inputs and outputs (from 11 to 30 terminal connectors).




Figure 4.1: 3CPI Front View.




Figure 4.2: 8CPI Front View.




Figure 4.3: 8CPI Rear View.

## 4.2 Dimensions

#CPI protection terminal case dimensions are 1/7 of a 19" rack wide, and 6 standard rack units high (10½"). 3CPI terminals are vertical mount units, and 8CPI terminals are horizontal mount units. The equipment is intended to be installed either semi-flush mounted on panels or inside a 19" rack. The #CPI is equipped with a transparent cover which can be sealed for security purposes. The enclosure color is graphite.

**Note:** 8CPI models are designed to be mounted on 1 Rack wide x 2U high adapter element. Dimension drawings for this adapter are given at the end of this instruction manual.




Figure 4.4: 3CPI Rear View.



### 4.3 Connection Elements

#### 4.3.1 Terminal Connectors

Terminal connectors are permanently attached to the rear edge of the printed circuit board to facilitate external wiring and are arranged in rows or columns depending on the model.

- One row or column of 10 terminal connectors for transformer secondary inputs.
- One row or column of 20 terminal connectors for power supply input and contact inputs and outputs.

Voltage analog input terminals accept up to #11 AWG wire. The remaining circuit terminals permit wire up to #14 AWG. Communications connectors are provided on both front and rear equipment panels.

#### 4.3.2 Removing Printed Circuit Boards (Non Self-Shorting)

The equipment has been designed to enable removal of the printed circuit board. The printed circuit board is attached to the case using self-tapping screws. These screws must be removed before the board is withdrawn. It is also necessary to remove the screws on the terminal connectors.

#### 4.3.3 Internal Wiring

The equipment uses traditional printed circuit board connections and internal buses to minimize internal wiring.

# 5. Settings



---

5.1	Configuration Settings.....	5-2
5.2	General Settings .....	5-2
5.3	Protection Elements Settings.....	5-3
5.4	Digital Inputs, Auxiliary Outputs and LED Targets .....	5-4

---



## 5.1 Configuration Settings

Communications (Local Port RS232C)	
Setting	Range
Terminal Address	Not sensitive - enter any number
Baud Rate	4800 Baud
Stop Bits	1
Parity	1 (even)

Communications (Remote Port)	
Setting	Range
Terminal Address	0 to 254
Baud Rate	300 to 19200 bauds <sup>(1)</sup>
Stop Bits	1 or 2
Parity	1 (parity) or 0 (no parity)
MODBUS Protocol <sup>(2)</sup>	YES / NO <sup>(3)</sup>

(1) Maximum baud rate for RS-232: 9600 bauds.

(2) Depending on the model.

(3) With NO setting answers Procome Protocol.

Communications (HMI)		
Setting	Range	By Default
Frontal Port Parity (affects to local port)	0 or 1	1
Time Out (affects to local and remote port)	0 to 1000 ms	100 ms

Language	
Setting	Range
Language <sup>(1)</sup>	Spanish English Portuguese

(1) Accord to software version.

Frequency	
Setting	Range
Frequency <sup>(1)</sup>	50 / 60 Hz

(1) Accord to software versión.

## 5.2 General Settings

General Settings		
Setting	Range	Step
Phase CT Ratio (#CPI-A/B)	1-3000	1
Ground CT Ratio (#CPI-B/C)	1-3000	1
Event masking	only via communications	



### 5.3 Protection Elements Settings

Phase Time Overcurrent Element (#CPI-A/B)		
Setting	Range	Step
Enable	YES/NO	
Pickup	(0.2-2.4) In	0.01 A
Time Curve	Definite time Inverse Very Inverse Extr. Inverse	
Time Dial	0.05-1	0.01
Definite Time Delay	0.05-100s	0.01 s

Phase Instantaneous Overcurrent Element (#CPI-A/B)		
Setting	Range	Step
Enable	YES/NO	
Pickup	(0.1-30) In	0.01 A
Time Delay	0-100s	0.01 s

Ground Time Overcurrent Element (#CPI-B/C)		
Setting	Range	Step
Enable	YES/NO	
Pickup	(0.04-0.48) In	0.01 A
Time Curve	Definite Time Inverse Very Inverse Extr. Inverse	
Time Dial	0.05-1	0.01
Definite Time Delay	0.05-100s	0.01 s
20 mA Ground Time Overcurrent Unit	0.16 to 2 mA	0.01 mA
Sensitive Ground Time Overcurrent Unit	0.01 to 0.24 A	0.01A
Optional Ground Unit (only #CPI-B)	(0.1-1.2) In	0.01A

Ground Instantaneous Overcurrent Element (#CPI-B/C)		
Setting	Range	Step
Enable	YES/NO	
Pickup (standard)	(0.1-12) In	0.01 A
Time Delay	0-100s	0.01 s
20 mA Ground Instantaneous Overcurrent Unit	0.16 to 4.8 mA	0.01 mA
Sensitive Ground Instantaneous Overcurrent Unit	0.05 to 3 A	0.01 A
Optional Ground Unit (only #CPI-B)	(0.1-30) In	0.01 A
Optional Ground Unit (only #CPI-C*G)	(0.02-6) In	0.01 A



## 5.4 Digital Inputs, Auxiliary Outputs and LED Targets

### Digital Inputs, Auxiliary Outputs and LED Targets Configuration

The **ZiverCom**® communications program allows a user to redefine or reallocate the Auxiliary outputs via the local communication port.

It is also possible to configure auxiliary outputs as NO or NC contacts, by changing the internal jumpers as indicated in figure 5-1.




Figure 5.1: Internal Jumpers.

# 6. Description of Operation



---

6.1	Overcurrent Units.....	6-2
6.1.1	Time Elements.....	6-2
6.1.1.a	Time/Current Characteristics.....	6-3
6.1.2	Overcurrent Unit Block Diagram.....	6-6
6.1.3	Instantaneous Elements.....	6-6
6.2	General Settings.....	6-7
6.2.1	Transformer Ratio.....	6-7
6.2.2	Event Masking.....	6-7
6.3	Event Recording.....	6-7
6.4	Contact Inputs, Outputs & LED Targets.....	6-10
6.4.1	Status Contact Inputs.....	6-10
6.4.2	Auxiliary Contact and Trip Outputs.....	6-11
6.4.3	LED Targets.....	6-13
6.5	Communications.....	6-14
6.5.1	Communications Settings.....	6-14
6.5.2	Communications Types.....	6-14
6.5.3	Communicating with the Unit.....	6-14

---



### 6.1 Overcurrent Units

**#CPI-A** terminals provide Three-Phase Instantaneous and Time Overcurrent protection. **#CPI-B** terminals provide Three-Phase and Ground Instantaneous and Time Overcurrent protection. **#CPI-C** terminals provide Ground Instantaneous and Time Overcurrent protection.

**Note:** ground units of the **#CPI-\*\*\*\_\*\*\*010\*\*** models don't trip.

Each of these overcurrent protection functions consists of an Instantaneous and a Time Overcurrent measuring element. The Instantaneous measuring element is also equipped with an adjustable timer that can be enabled or disabled. Instantaneous and Time Overcurrent element settings are made for Phase and Ground functions. Consequently, all three phases share the same Phase Instantaneous and Phase Time Overcurrent settings. The following parameters are adjustable for each of the setting groups:

- **Enable**
- **Pickup**
- **Definite Time Delay**

#### 6.1.1 Time Elements

The Time Overcurrent element continuously processes the RMS value of current analog input **I** based on averaging a full cycle of samples. Pickup takes place when the measured value exceeds 1.05 times the pickup setting, and reset occurs at the pickup setting.

The time element integrates a measured value above pickup by incrementing a counter in the integrator module using an amount proportional to the input current RMS value. When the counter reaches the operate threshold, the Time Overcurrent element initiates a trip. When the measured value drops below the pickup setting, the incrementing value is removed, causing a rapid reset of the integrator module to its initial condition with the counter at zero. Any new measured value above pickup must then start the integration interval from zero.

Three inverse time curves (Inverse, Very Inverse and Extremely Inverse), one definite time delay and one user defined time curve can be selected. The user defined curve is loaded into the Terminal Unit front RS232 port through the **ZiverCom**® communications program. Time-current characteristic curves have two independent settings: curve family, and time dial.



### 6.1.1.a Time/Current Characteristics

Figures 6.1, 6.2 and 6.3 show the pre-programmed time/current characteristic curves provided with the #CPI Terminal Unit.




Figure 6.1: Inverse Time/Current Characteristic.

$$t = \frac{0.14}{I_S^{0.02} - 1}$$




Figure 6.2: Very Inverse Time/Current Characteristic.

$$t = \frac{13.5}{I_S - 1}$$




Figure 6.3: Extremely Inverse Time/Current Characteristic.

$$t = \frac{80}{I_S^2 - 1}$$



### 6.1.2 Overcurrent Unit Block Diagram




Figure 6.4: Overcurrent Unit Block Diagram.

### 6.1.3 Instantaneous Elements

The instantaneous elements respond using two different current measuring criteria, one for RMS values and the other for peak-to-peak values. For RMS current values, operation takes place whenever the measured value exceeds 1.05 times the pickup setting. For peak-to-peak current values, operation occurs whenever there are two consecutive samples, whose value exceeds 2.1 times the peak value of the pickup setting. The RMS level detector and the peak-to-peak level detector will reset whenever the measured value is below the pickup setting.

Filtering out the DC offset component in combination with the application of these two instantaneous measurement methods results in low transient overreach without adversely affecting tripping speed.

The combined output of these measuring elements is equipped with an adjustable timer that enables delay of the instantaneous trip.



## 6.2 General Settings

### 6.2.1 Transformer Ratio

The transformer ratio settings (phase and/or ground, depending on model) only affect to the analog values displayed on the HMI. A transformer ratio setting of 1 will display the secondary values of the CTs. A setting equivalent to the CT transformation ratio will display the primary values of the system.

### 6.2.2 Event Masking

It is possible to mask unneeded events or those events without importance for the study of protection behavior. Event masking can be done only through **ZiverCom**® communications software.

## 6.3 Event Recording

Protection functions that are monitored by the **Sequence of Events** feature are listed in Table 6-1.

Function	Event	oct.	bit	#CPI-A	#CPI-B	#CPI-C
Overcurrent Elements Activation [OC]	Phase A Time Overcurrent Pickup	1	1	✓	✓	
	Phase B Time Overcurrent Pickup	1	2	✓	✓	
	Phase C Time Overcurrent Pickup	1	3	✓	✓	
	Ground Time Overcurrent Pickup	1	4		✓	✓
	Phase A Instantaneous Overcurrent Pickup	1	5	✓	✓	
	Phase B Instantaneous Overcurrent Pickup	1	6	✓	✓	
	Phase C Instantaneous Overcurrent Pickup	1	7	✓	✓	
	Ground Instantaneous Overcurrent Pickup	1	8		✓	✓
	Phase A Time Overcurrent Trip Output Active	2	1	✓	✓	
	Phase B Time Overcurrent Trip Output Active	2	2	✓	✓	
	Phase C Time Overcurrent Trip Output Active	2	3	✓	✓	
	Ground Time Overcurrent Trip Output Active	2	4		✓	✓
	Phase A Instantaneous Trip Output Active	2	5	✓	✓	
	Phase B Instantaneous Trip Output Active	2	6	✓	✓	
	Phase C Instantaneous Trip Output Active	2	7	✓	✓	
	Ground Instantaneous Trip Output Active	2	8		✓	✓



**Table 6-1: Events**

Function	Event	oct.	bit	#CPI-A	#CPI-B	#CPI-C
Overcurrent Elements Reset and Deactivation [10]	Phase A Time Overcurrent Reset	1	1	✓	✓	
	Phase B Time Overcurrent Reset	1	2	✓	✓	
	Phase C Time Overcurrent Reset	1	3	✓	✓	
	Ground Time Overcurrent Reset	1	4		✓	✓
	Phase A Instantaneous Overcurrent Reset	1	5	✓	✓	
	Phase B Instantaneous Overcurrent Reset	1	6	✓	✓	
	Phase C Instantaneous Overcurrent Reset	1	7	✓	✓	
	Ground Instantaneous Overcurrent Reset	1	8		✓	✓
	Phase A Time Overcurrent Trip Output Deactivated	2	1	✓	✓	
	Phase B Time Overcurrent Trip Output Deactivated	2	2	✓	✓	
	Phase C Time Overcurrent Trip Output Deactivated	2	3	✓	✓	
	Ground Time Overcurrent Trip Output Deactivated	2	4		✓	✓
	Phase A Instantaneous Trip Output Deactivated	2	5	✓	✓	
	Phase B Instantaneous Trip Output Deactivated	2	6	✓	✓	
	Phase C Instantaneous Trip Output Deactivated	2	7	✓	✓	
	Ground Instantaneous Trip Output Deactivated	2	8		✓	✓
Initialization [13]:	Power up	1	8	✓	✓	✓
	Change Of Settings Initialization	1	7	✓	✓	✓
Inputs [06]:	Status Contact Input IN-2 Active	1	2	✓	✓	✓
	Status Contact Input IN-1 Active	1	1	✓	✓	✓
	Status Contact Input IN-2 Deactivated	2	2	✓	✓	✓
	Status Contact Input IN-1 Deactivated	2	1	✓	✓	✓
	Status Contact Input IN-2 Disabled	3	2	✓	✓	✓
	Status Contact Input IN-1 Disabled	3	1	✓	✓	✓
Commands [05]:	Trip Blocked Due to Setting Disagreement	1	2	✓	✓	✓
	Breaker Open Command	1	8	✓	✓	✓
HMI [09]:	Local Mode (Keypad and Display)	1	5	✓	✓	✓
	Remote Mode (Rear Port)	1	6	✓	✓	✓
	Local Mode (Front Port)	1	7	✓	✓	✓



- **Event Recorder Management**

The event record capacity is one hundred (100) events. The Event Recorder structure is a FIFO stack. Once the full capacity is reached, a new event overwrites the oldest event. The following information is stored in each event register:

- **Phase and ground currents (depending on model) measured at the moment the event was generated**
- **Event date and time and event description**

The management of the event recorder is optimized so that simultaneous operations generated by the same event occupy a single position in the event memory. For example, the simultaneous occurrence of the Phase A and the Ground Time Overcurrent Pickups are recorded in the same memory position. However, if the occurrences were not simultaneous, two separate events would be generated. Simultaneous events are defined as those operations that occur within a 1 ms interval, which is the resolution time of the recorder.

**Important:** There is the option of masking those events that the user considers unnecessary for the analysis of relay operations. Since the capacity of the relay is 100 events, the recording of unnecessary data may erase important information.

- **Records retrieval**

**ZiverCom**<sup>®</sup> communications software allows the user to retrieve the information recorded by the unit. Information is decoded for user friendly presentation. Information is presented in table format with a record per table entry.



## 6.4 Contact Inputs, Outputs & LED Targets

#CPI terminal units are provided with programmable inputs and outputs enabling user configuration of flexible logic designs. The following paragraphs contain a description of the programming structure to configure protection inputs, outputs and signaling. Factory default settings may be modified using the **ZiverCom**® software program.

### 6.4.1 Status Contact Inputs

The terminal unit metering elements, and logic functions use the Logic Input Signals listed in Table 6-2 below. Any of these Logic Input Signals can be assigned to one of the two Status Contact Inputs of the terminal unit. The closure of a contact will thereby activate those Logic Input Signals assigned to it. Several different Logic Input Signals can be assigned to one Status Contact Input, but a given Logic Input Signal can only be assigned to one Status Contact Input.

No.	Name	Description	#CPI-A	#CPI-B	#CPI-C
6	EPT	External Protection Trip	✓	✓	✓
7	BP_TOC_PH	Bypass Time Phase Time Overcurrent	✓	✓	
8	BP_TOC_N	Bypass Time Ground Time Overcurrent		✓	✓
9	BLK_IOC_PH	Block Phase Instantaneous Overcurrent Trip	✓	✓	
10	BLK_IOC_N	Block Ground Instantaneous Overcurrent Trip		✓	✓
11	BLK_TOC_PH	Block Phase Time Overcurrent Trip	✓	✓	
12	BLK_TOC_N	Block Ground Time Overcurrent Trip		✓	✓

**Note:** Depending on the model, each unit have available the signals indicated by the check mark.

Users can easily program different input settings using the local RS232 communications port and the **ZiverCom**® software, or can request this to be completed by the manufacturer.

#### • Input Properties

Input **EPT** blocks trips from every element, provided that it is active before trip is generated.

Inputs **BP\_TOC\_PH** and/or **BP\_TOC\_N** change the phase and ground time units into instantaneous units when the input is active before the unit pickup. When the input becomes active after the pickup has occurred, the time delay is bypassed and a trip command is issued.

**BLK\_IOC\_PH**, **BLK\_IOC\_N**, **BLK\_TOC\_PH**, and **BLK\_TOC\_N** block the trip output for the corresponding units. When the input becomes active after the trip has occurred, the trip contact will reset.



### 6.4.2 Auxiliary Contact and Trip Outputs

#### • Auxiliary Contact Outputs

#CPI units are provided with three auxiliary contact outputs. Two of these contacts (AUX-1 and AUX-2) are programmable. Auxiliary Contact Output (AUX-3), which corresponds to **Relay in Service**, is not programmable. Auxiliary contacts location and configuration procedure is outlined in chapter 4 of this manual.

Terminal unit metering elements and logic functions generate a series of Logic Output Signals during terminal unit operation. Each of these signals has either a “True” or “False” value and this status can be used as an input to either of the combinational logic gates shown in Figure 6.5.

Two logic gates are available in each cell (one “**OR**” gate and one “**AND**” gate). Each gate accepts up to eight Logic Output Signals. The output of these two gates is operated by a selectable second gate. The desired final “**AND**” or “**OR**” output from the logic cell can then be connected to any one of the two programmable Auxiliary Contact Outputs (AUX-1 and AUX-2) available in the terminal unit. There are two output modes, pulsed or without pulse.

- **Without Pulses:** Setting the pulse timer to “0”, the output contact remains active as long as the forcing function is present.
- **With Pulses:** Once the forcing function activates the output, the contact remains active during the time set independent of the length of the forcing function.




Figure 6.5: Auxiliary Contact Output Logic Cell Block Diagram.



Table 6-3: Auxiliary Contact Outputs

No.	Name	Description	#CPI-A	#CPI-B	#CPI-C
1	TOCT_A	Phase A Time Overcurrent Trip Output Active	✓	✓	
2	TOCT_B	Phase B Time Overcurrent Trip Output Active	✓	✓	
3	TOCT_C	Phase C Time Overcurrent Trip Output Active	✓	✓	
4	TOCT_N	Ground Time Overcurrent Trip Output Active		✓	✓
5	IOCT_A	Phase A Instantaneous Trip Output Active	✓	✓	
6	IOCT_B	Phase B Instantaneous Trip Output Active	✓	✓	
7	IOCT_C	Phase C Instantaneous Trip Output Active	✓	✓	
8	IOCT_N	Ground Instantaneous Trip Output Active		✓	✓
9	TOCP_A	Phase A Time Overcurrent Pickup	✓	✓	
10	TOCP_B	Phase B Time Overcurrent Pickup	✓	✓	
11	TOCP_C	Phase C Time Overcurrent Pickup	✓	✓	
12	TOCP_N	Ground Time Overcurrent Pickup		✓	✓
13	IOCP_A	Phase A Instantaneous Overcurrent Pickup	✓	✓	
14	IOCP_B	Phase B Instantaneous Overcurrent Pickup	✓	✓	
15	IOCP_C	Phase C Instantaneous Overcurrent Pickup	✓	✓	
16	IOCP_N	Ground Instantaneous Overcurrent Pickup		✓	✓
44	ALARM_PRO	Protection Module Alarm	✓	✓	✓
54	OPEN	Opening Command	✓	✓	✓
56	DISP	Protection Trip Active	✓	✓	✓
98	ALARMAERR	Error Module Alarm	✓	✓	✓
99	IN_1	Physical Input 1	✓	✓	✓
100	IN_2	Physical Input 2	✓	✓	✓

### • Trip Output

#CPI models are provided with two trip output relays, each with two contacts. These contacts are internally configurable to NO or NC. Trip contacts correspond to terminal connectors 15-16 and 17-18. Trip outputs location and configuration procedure is outlined in chapter 4 of this manual.



### 6.4.3 LED Targets

CPI terminals are provided with eight optical indicators (**LEDs**) located on the front panel. Seven of the **LEDs** are user definable. The eighth **LED** is always assigned to indicate the terminal unit is "**Ready**" (powered up, self-test OK).

The logic cell structure, shown in the block diagram of Figure 6.6, permits the user to create combinational logic equations for the **LED Target Outputs**. To configure **LED Target Outputs**, Logic Output Signals are assigned to a **LED Target Output**. The available Logic Output Signals are shown in Table 6-3.




Figure 6.6: LED Target Output Logic Cell Block Diagram.

Each **LED** can be defined as latched or unlatched. If an **LED** is latched it will remain illuminated until reset, even after a condition has disappeared. The **LED** reset function is accomplished via the keypad ↓ (see Chapter 7: Alphanumeric Keypad and Display).

The latching function resides in the volatile memory section of the microprocessor. A power supply loss will cause any latched **LED** to be reset.

Each **LED** can be assigned to any Logic Output Signal listed in Table 6-3.



## 6.5 Communications

### 6.5.1 Communications Settings

Communications settings are listed in Chapter 5 (Settings) and include **Terminal Unit Address**, **Baud Rate**, **Stop Bits**, and **Parity**.

### 6.5.2 Communications Types

**#CPI** Terminals contain two communications ports. The local port located on the front panel is an RS232 DB-9 port with fixed settings. The remote port is optional, and can be glass fiber optics, 1mm plastic fiber optics, RS232 or RS485 type. Technical data relative to these ports is listed in Chapter 2 (Technical Data).

### 6.5.3 Communicating with the Unit

Communications with the unit through the communication ports is achieved using the **ZiverCom**<sup>®</sup> software application. This software is designed to connect with units of the **#CPI** family, allowing operations such as programming, settings configuration, event recording, activity reports, etc.

It is also possible using **PROCOME**, **DNP3.0** or **MOD-BUS** protocol (according to model), to communicate with equipment to request control and metering changes and to execute commands.

Remote port communication settings can be modified only via the HMI. Local port communication settings are fix to 4800 baud, 1 stop bit and adjustable parity, as listed in Chapter 5.

**#CPI** models are provided with two communication controllers. This enable simultaneous communications via both ports.

**ZiverCom**<sup>®</sup> is password protected to provide access only to authorized personnel. **ZiverCom**<sup>®</sup> is a user-friendly, Windows<sup>™</sup> based software tool. The software allows easy navigation of and access to available settings and actions through a series of intuitive menus and graphical user interfaces.

Terminal unit status information can be accessed either in local or remote mode. The following data can be retrieved:

Metering data	Contact inputs/outputs status
Settings	Protection element status
Contact inputs	Last trip information
Auxiliary outputs & LED targets	Time and Date
Event records	

# 7. Alphanumeric Display and Keypad



---

7.1	Alphanumeric Display and Keypad.....	7-2
7.2	Keys, Functions and Operation Modes.....	7-2
7.3	Screen Sequence using a Single Key .....	7-4
7.4	Screen Sequence using the Complete Keypad.....	7-7

---



## 7.1 Alphanumeric Display and Keypad

The dot matrix display has four characters, each one being a 7 x 5 dot matrix. It provides information on terminal unit alarms, settings, metering, status, etc. The default screen displays model identification (**#CPI**) as shown in Figure 7.1.



Figure 7.1: Alphanumeric Display.

The **#CPI** keypad consists of 3 keys (see Figure 7.2). This keypad is associated with the information on the Alphanumeric Display. Only one key is accessible (the **↓** key) when the cover is installed on the equipment.

Starting from the default screen, the Local Interface has two possible operation modes. One mode operates using only a single key (when the cover is installed), and the other takes advantage of the complete keypad.




Figure 7.2: Keypad.

## 7.2 Keys, Functions and Operation Modes

- **Option Selection**

Using the selection keys (**↑↓**) is possible to scroll through the different options on the display. The **ENT** key is used to confirm a selection.

To scroll through different settings use the **↓** key. Once the desired setting is found, use the **ENT** to select it. The setting value will be displayed. If these setting value needs to be changed, press the **ENT** key a second time and the setting value will blink.



- **Change of Settings (Range)**

For settings with a numeric value (inside a range) the procedure is as follows: The first digit in the setting will blink. Pressing the **↑** key is possible to scroll through the different values for that digit. Once the selection is made, press the **↓** key to set it and the next digit will blink. Repeat the procedure until the setting value is completed.

For digits where no changes are desired, press the **↓** key to skip to the next digit. Once every digit has been adjusted press the **ENT** key to set the value and the screen will show the setting identifier. Proceed to the next setting by pressing the **↓** key.

The system does not allow to exceed the range for a given setting. When setting a value out of range, the value resets to zero and the blinking cursor is placed on the first digit.

- **Change of Settings (Options)**

For settings with preset options, it is possible to scroll through the different values using the **↑** and **↓** keys. Once the selection is displayed, press the **ENT** key to set the value and the screen will show the setting identifier. Proceed to the next setting by pressing the **↓** key.

- **Exit Menus or Settings**

After an operation has been performed (selection, change of settings, viewing information, etc.) move to the previous level in the menu by pressing the **↑** key.7.3.



### 7.3 Screen Sequence using a Single Key

From the default screen, press the ↓ key to access the following screen sequence:

- Phase and ground current metering (depending on model).
- Last relay trips since last reset.
- Reset trip information.
- Reset LEDs.

Figure 7.3 shows the sequence after a trip has occurred. Figure 7.4 sequence starts without trip indication. The white areas shown in both Figures depict screen groups dependent on the #CPI model, with different content for each model. The shaded areas depict screen common for each model. The screen mnemonics are explained in the following paragraphs.




Figure 7.3: General Screen Sequence using the ↓ Key (with Trip Indication).




Figure 7.4: General Screen Sequence using the ↓ Key (without Trip Indication).



## Chapter 7. Alphanumeric Display and Keypad

The screen mnemonics included in Figures 7.3 and 7.4 are explained in the following paragraphs.

**TRIP**  
**DISP** Screen indicating a protection trip.

**RST?**  
**DIS?** Trip Indication Reset. Once the trip conditions have been removed, it is possible to reset the trip indication by pressing and holding the ↓ key for more than two (2) seconds.

**LEDS** It is possible to reset the trip indication by pressing and holding the ↓ key for more than two (2) seconds.

The following Figures depict the screen groups including metering and trip indications. These sequences are model dependent, corresponding to the white areas in Figure 7.3.




Figure 7.5: Metering Elements and Trip Information Screen Sequence. #CPI-A Model.




Figure 7.6: Metering Elements and Trip Information Screen Sequence. #CPI-B Model.




Figure 7.7: Metering Elements and Trip Information Screen Sequence. #CPI-C Model.



The screen mnemonics included in Figures 7.5, 7.6 and 7.7 are explained in the following paragraphs.

**A :** Indicates that the value displayed in the next screen corresponds to the real time measurement of the current circulating on Phase A.

**B :** Indicates that the value displayed in the next screen corresponds to the real time measurement of the current circulating on Phase B.

**C :** Indicates that the value displayed in the next screen corresponds to the real time measurement of the current circulating on Phase C.

**N :** Indicates that the value displayed in the next screen corresponds to the real time measurement of the ground current.

**0.00** Measured value in Amps, indicating primary values (according to the CT ratio set in the relay). The value correspond to the phase or ground, as indicated in the previous screen.

**TRIP**  
**DISP** Indicates that a protection trip has occurred, and has not been acknowledged. Following to these screen are the indication of the elements issuing the trip command.

**TOCX**  
**DT\_X** Indicates a Time Overcurrent trip by element X. Depending on the #CPI model, X can take the value A, B, C, or N.

**IOCX**  
**DI\_X** Indicates an Instantaneous Overcurrent trip by element X. Depending on the #CPI model, X can take the value A, B, C, or N.

Always that a protection trip command is issued, the relay will display the **TRIP** (or **DISP**) indication, followed by the tripped elements. If more than an element is under trip conditions, the screens shown will **not** be in chronological sequence.

These screens will be displayed always that a protection trip command is issued. Once the trip conditions are eliminated, the screens will remain until reset from the **RST?** (or **DIS?**) screen. Once the indications are reset, screens **TRIP** (or **DISP**), **TOC X** (or **DT\_X**), and **IOC X** (or **DI\_X**) are replaced by **RST** (or **REPU**).



### 7.4 Screen Sequence using the Complete Keypad

From the default screen (see Figure 7.1), there are a series of screen sequences. Using the selection keys (↑↓) and the ENT key is possible to access the following options:

- **Settings**
  - general
  - protection
- **Information**
  - contact input status
  - contact output status
  - protection elements status
  - selected language
  - frequency
- **Configuration**
  - communications
  - language
  - frequency

For a global display of the screen sequence and the keys used to move forward in the sequence, below is a table describing the process.

• **General Settings: HMI Access**

<b>SETT</b>	<b>GNRL</b>	<b>PCT:</b>
INFO	PRO	<b>NCT:</b>
CNFG		

• **Protection Settings: HMI Access**

<b>SETT</b>	<b>GNRL</b>	<b>TOCP</b>	<b>ENBL</b>
INFO	<b>PRO</b>	TOCN	<b>PKUP</b>
CNFG		IOCP	<b>CURV</b>
		IOCN	<b>DIAL</b>
			<b>TIME</b>

<b>SETT</b>	<b>GNRL</b>	<b>TOCP</b>	<b>ENBL</b>
INFO	<b>PRO</b>	<b>TOCN</b>	<b>PKUP</b>
CNFG		IOCP	<b>CURV</b>
		IOCN	<b>DIAL</b>
			<b>TIME</b>

<b>SETT</b>	<b>GNRL</b>	<b>TOCP</b>	
INFO	<b>PRO</b>	TOCN	<b>ENBL</b>
CNFG		<b>IOCP</b>	<b>PKUP</b>
		IOCN	<b>TIME</b>

<b>SETT</b>	<b>GNRL</b>	<b>TOCP</b>	
INFO	<b>PRO</b>	TOCN	<b>ENBL</b>
CNFG		IOCP	<b>PKUP</b>
		<b>IOCN</b>	<b>TIME</b>



- **Information Menu: HMI Access**

SETT	D_IN
<b>INFO</b>	DOUT
CNFG	PKUP
	LANG
	FREQ

- **Configuration Menu: HMI Access**

SETT		ADDR
INFO	COMN	RATE
<b>CNFG</b>	LANG	STOP
	FREQ	PARI
		MODB
		FPAR
		TOUT

SETT		
INFO	COMN	ENGL
<b>CNFG</b>	LANG	PORT
	FREQ	SPAN

SETT		
INFO	COMN	
<b>CNFG</b>	LANG	50Hz
	FREQ	60Hz

# 8. Receiving Tests



---

8.1	General .....	8-2
8.1.1	Accuracy .....	8-2
8.2	Preliminary Inspection .....	8-3
8.3	Insulation Test.....	8-3
8.4	Current Measuring Test.....	8-4
8.5	Phase and Ground Units Test .....	8-4
8.6	Contact Inputs, Auxiliary Outputs and LED Targets Test.....	8-5
8.7	Communication Test.....	8-5
8.8	Installation.....	8-6
8.8.1	Location .....	8-6
8.8.2	Connection.....	8-6

---



## 8.1 General

Improper handling of electrical equipment is extremely dangerous, therefore, only skilled and qualified personnel familiar with appropriate safety procedures and precautions should work with this equipment. Damage to equipment and injury to personnel can result when proper safety precautions are not followed. The following general safety precautions are provided as a reminder:

- High magnitude voltages are present in auxiliary supply and measuring circuits **even after equipment has been disconnected**.
- Equipment should be solidly grounded before handling or operating.
- Under no circumstances should the operating limits of the equipment be exceeded (auxiliary voltage, current, etc.).
- The auxiliary supply voltage (AC or DC) should be disconnected from the equipment before extracting or inserting any module, otherwise damage may result.

The number, the type and the specific characteristics of the acceptance tests for the **#CPI** units are detailed in the following table.

<b>#CPI</b>	Preliminary inspection
	Insulation test
	Current measuring test
	Phase and Ground Units Test
	Status contact inputs & LED targets test
	Communications test

### 8.1.1 Accuracy

The results obtained in electrical testing greatly depend on the accuracy of the measuring instruments and test source signals (auxiliary voltage, and measurement voltages). Therefore, verification of the information specified in the Technical Data section of this manual can only reasonably be achieved using test equipment under normal reference conditions and with the tolerances indicated in the UNE 21-136 and IEC 255 standards, in addition to using precision instruments.

It is extremely important that there be no distortion (<2%) in the test source signals as harmonics can affect internal measuring of the equipment. For example, distortions will affect this unit, made up of non-linear elements, differently from an AC ammeter, because the measurement is made differently in both cases.

It must be emphasized that the accuracy of the test will depend on the instruments used for measuring as well as the source signals used. Therefore, tests performed with secondary equipment should focus on operation verification and not on measuring accuracy.



## 8.2 Preliminary Inspection

The following equipment aspects should be examined:

- The unit is in good physical condition, mechanical parts are securely attached and no assembly screws are missing.
- The unit model number and specifications agree with the equipment order.

## 8.3 Insulation Test

While testing for insulation of switchgear and external wiring, is recommended to disconnect the terminal unit to avoid damage, since insulation testing has been performed by the manufacturer. The following paragraphs describe common mode and transverse mode insulation tests.

### • Common Mode

With no wires connected to the unit, wire all the rear connection terminals together except for number 10, number 30, and the ground terminal. With external wiring connected, disconnect terminals 28, 29, 30, and the ground terminal. Apply 2,000 Vac for 1 minute between interconnected terminals and metal case.

### • Transverse Mode

Divide the terminals into terminal groups according to Table 8-1. Apply 2000 VAC for 1 minute between pairs of terminal groups.

Table 8-1: Insulation Test (Transverse Mode)		
#CPI-A	#CPI-B	#CPI-C
1-2	1-2	---
3-4	3-4	---
5-6	5-6	---
---	7-8	7-8
11-12-13-14	11-12-13-14	11-12-13-14
15-16-17-18	15-16-17-18	15-16-17-18
19-20-21-22-23-24-25-26-27	19-20-21-22-23-24-25-26-27	19-20-21-22-23-24-25-26-27
28-29	28-29	28-29

High voltage may be present after testing due to internal capacitors. Gradually, reduce test voltage to zero, before removing the test probes.



## 8.4 Current Measuring Test

To avoid trips while performing this test, protection elements must be disabled and the test current should not be interrupted by the breaker. Apply the a.c. current values indicated in table 8-2 to the Phase and Ground Current Analog Inputs – terminal connectors are model dependent.

Table 8-2: Current Measuring Test	
Applied Current	Measured Value
X Aac	$X \pm 5\% \text{ Aac}$

**Note:** for high current values, apply test current for the shortest time possible. Do not exceed 8 seconds for 20 A input current.

## 8.5 Phase and Ground Units Test

It is recommended to test each unit individually. Disable every unit but the unit to be tested.

- Pickup and Reset**

Adjust the desired settings in the terminal unit, and apply current to the corresponding analog input. To verify pickup and reset values, set the display to the Information - Pickup menu. Auxiliary outputs can also be programmed to verify element pickup and reset.

Table 8-3: Phase and Ground Units Test				
Setting	Pickup		Reset	
	Maximum	Minimum	Maximum	Minimum
X	$1.10 \times X$	$1 \times X$	$1.05 \times X$	$0.95 \times X$

- Operating Times**

Operating times can be verified monitoring the trip outputs (terminals 15-16 and 17-18).




Figure 8.1: Operating Time Test Setup.



### Fixed Time or Instantaneous

Apply a current value 20% over the pickup setting. Operating time should be the time setting  $\pm 5\%$  or  $\pm 25$  ms (whichever is greater). Note that minimum operating speed for instantaneous operation averages 30 ms.

### Inverse Time

For a given curve, operation time depends on the time dial setting and the applied current (refer to chapter 6 for time/current characteristic curves). Tolerance is  $\pm 5\%$  of the current value.

## 8.6 Contact Inputs, Auxiliary Outputs and LED Targets Test

Connect the equipment to a suitable power supply (rated Vdc) through terminal connectors 28 (+) and 29 (-). Ready LED will illuminate.

Apply rated voltage to the contact input connectors 11(+) – 12(-) and 13(+) – 14(-). Select from the information menu the inputs status screens (refer to Chapter 7 Operator Interface) and verify that both signals are ON. Disconnect the test probes and verify that both signals are OFF.

To test auxiliary outputs, the forcing function to activate the output depends on how the outputs are configured. A straight forward test is to program the outputs to activate when the physical inputs are energized. In this fashion the inputs test doubles as the output operation test.

Press the  $\downarrow$  key to scroll through the screen sequence until the screen LEDS is reached. Then, press the  $\downarrow$  key for 2 seconds and verify that all the LEDs illuminate. Release the  $\downarrow$  key and verify that all the LEDs turn off.

## 8.7 Communication Test

Connect the equipment to a suitable power supply (rated Vdc) through terminal connectors 28 (+) and 29 (-). Ready LED will illuminate. Test will be performed through local communications port, allocated on front panel. This port has fixed settings as follows:

Baud Rate	4800 bauds
Stop Bits	1
Parity	1 (even)

Connect to the terminal unit through the local communications port using a DB9 (9-pin) serial connection wire. Synchronize time using the **ZiverCom**<sup>®</sup> software program. Disconnect the communications wire and disconnect the terminal unit power supply and wait for two minutes. Afterwards, connect the power supply and connect to the terminal unit through the remote communications port. Activate the cyclical mode in the **ZiverCom**<sup>®</sup> software program and verify that time actualizes properly.



### 8.8 Installation

#### 8.8.1 Location

The location where the terminal unit is to be installed should meet the following minimum conditions to ensure correct operation, long service life, and ease of installation and maintenance:

- Absence of dust
- Absence of vibration
- Easy access
- Absence of dampness
- Adequate lighting
- Horizontal or vertical mounting

Mounting should be in accordance with the external connections scheme.

#### 8.8.2 Connection

Terminal number 30 should be solidly grounded to ensure disturbance filtering circuits operate properly. The wire used for grounding these terminals should be stranded 14 AWG. Ground wire length should be minimized and should not exceed 12”.

# A. Protection Communications Protocol PROCOME 3.0



---

A.1	Settings .....	A-2
A.1.1	Configuration Settings.....	A-2
A.2	Description of Operation .....	A-2
A.2.1	Event Record .....	A-2
A.2.2	Inputs .....	A-2
A.2.3	Communicating with the Unit .....	A-2
A.3	Alphanumeric Keypad and Display.....	A-3
A.3.1	Communications .....	A-3
A.3.2	Accessing the Information .....	A-3

---



Model-specific documentation with protection communications protocol PROCOME 3.0

## A.1 Settings

### A.1.1 Configuration Settings

Communications (HMI)	
Setting	Range
Communications password enable	YES / NO
Communications password timeout	1 - 1440 min
Communications password	8 characters

Settings for establishing communication through the remote port.

## A.2 Description of Operation

### A.2.1 Event Record

Table A-1: Event Record			
Function	Event	Oct.	Byte
33750	Measurement annotation	1	1

### A.2.2 Inputs

There exists the possibility of the physical inputs functioning with inverse logic, assigning one or a set of them to a digital input or to its negated.

### A.2.3 Communicating with the Unit

Using the PROCOME profile, it is possible to communicate with the unit to request control changes and to execute orders. In this case, the distance to the fault calculated by the locator is transmitted as one more measurement.



### A.3 Alphanumeric Keypad and Display

#### A.3.1 Communications

Selecting the communications option brings up a menu composed of the settings: Terminal Address, Baud Rate, Stop Bits, Parity, Frontal Port Parity, Communications Timeout, Communications Password Enable and Communications Password Timeout.

- **Communications Password Enable, Communications Password Timeout and Communications Password**

**P\_CL** The setting of **Communications Password Enable** makes it possible to enable the password access function to establish communication with the unit via the rear port: YES means enabling the permission and NO, disabling.

**T\_CL** The setting of **Communications Password Timeout** allows establishing a period of time for activating a lockout of communication with the unit (whenever communication is via the rear port): if the set time elapses with no activity taking place in the communications program, the system locks itself in this state. Consequently, it will be necessary to restart the communication.

The last setting of the communications group, **Communications Password**, makes it possible to establish a specific password to access communication with the unit through the rear port (only through **ZiverCom**<sup>®</sup> communications program. This password must have 8 characters, which will be entered using the numerical keys and the key corresponding to a dot.

#### A.3.2 Accessing the Information

The variations in the settings menus described in the preceding sections are reflected in the information menus, with the same layout shown. Note that the information menu only allows viewing the established settings and does not allow modifying them.



# B. DNP 3.0 Communications Protocol



---

B.1	Physical Architecture .....	B-2
B.2	Settings .....	B-3
B.3	Description of Operation .....	B-3
B.3.1	DNP 3.0 Protocol .....	B-3
B.3.2	Communications .....	B-4
B.3.2.a	Communication with the Equipment .....	B-4
B.4	Alphanumeric Keypad and Display .....	B-4
B.4.1	DNP 3.0 Settings Menu ( <i>Zivercom</i> ®) .....	B-4

---



Model-specific documentation with communications PROTOCOL DNP 3.0

## B.1 Physical Architecture

Figures B.1 and B.2 shows de options for the **CPI** models (vertical and horizontal mounting).




Figure B.1: 3CPI Rear View.




Figure B.2: 8CPI Rear View.



### B.2 Settings

DNP 3.0 Protocol		
Setting	Range	Step
MTU Address (Master equipment number)	0 - 65534	1
RTU Address (Slave equipment number)	0 - 65534	1
Enable Unsolicited Reporting)	0 - 1	
Timeout N7	50 - 65535 ms	1 ms
Time Grouping Unsolicited	100 - 65535 ms	1 ms
N7 Retries Number	0 - 3	1
Pre-Transmission Time	0 - 65535 ms	1 ms
Echo Control Enable	0 - 1	
N2 Retries Number	0 - 32	1
Fixed Delay	0 - 32767 ms	1 ms
Max. Random Delay	0 - 32767 ms	1 ms

Metering Changes Settings		
Setting	Range	Step
Settings independents for metering changes from 0 to 5 % Change Metering	0.00 - 100 %	0.01 %

### B.3 Description of Operation

#### B.3.1 DNP 3.0 Protocol

The models with the option DNP 3.0 communication protocol present the following configuration settings:

- **DNP Configuration Settings**

The DNP 3.0 protocol configuration settings incorporate the definition of the **RTU** and **MTU** address (number of slave equipment and number of master equipment); the activation or deactivation of **Unsolicited**, the setting of **Timeout N7**, which fixes the time out to receive confirmation from the master asked by the slave with CON bit set to 1, the number of new attempts which can be applied when waiting for confirmation from the master, if it does not arrive repeatedly within the time fixed by the **Timeout N7**, the setting for the **Pre-Transmission Time** setting, time which generates the number of warning characters, and the one of **Echo Control**, i.e. the activation or deactivation of the transmission echo.

**Note:** Pre-Transmission Time and Echo Control settings are used to have various equipments connected to a concentrator type 4CCY and working in multi-master mode.

- **Metering Changes (Deadband Values)**

Analog metering bands (according to equipment and model) can be set. The setting represents the percentage over the maximum value of the measure, that will be taken as reference to test if there is an analogical change to record. In other word, a change will be recorded if the difference in the analogical measures is greater than the set percentage.

If it is adjusted to 100%, analogical changes in this measure will not be recorded, which is then understood as being in a deactivated state.



## B.3.2 Communications

### B.3.2.a Communication with the Equipment

The CPI models have a frontal and a rear communications port.

## B.4 Alphanumeric Keypad and Display

The settings of the communications protocol DNP3 are not adjustable locally from the relay itself. They can only be changed by using the communications program **Zivercom®**.

### B.4.1 DNP 3.0 Settings Menu (Zivercom®)

**PROTOCOLO DNP 3.0**

**Configuración DNP 3.0**

Número MTU	1	Timeout N7	1000 ms
Número RTU	1	Nº intentos N7	0
<input type="checkbox"/> Ctrl ECO		Tiempo de pre-transmisión	0 ms
Nº intentos N2	6	<input type="checkbox"/> Habilitar Mensajes No Solicitados	
Retardo Fijo	100 ms	Retardo en la transmisión de mensajes No Solicitados	1000 ms
Retardo Aleatorio	100 ms		

**Bandas muertas**

Med. 0	100.00 %	Med. 1	100.00 %	Med. 2	100.00 %
Med. 3	100.00 %	Med. 4	100.00 %	Med. 5	100.00 %

# C. MODBUS RTU Documentation. Address Map



---

C.1	Preliminary Information .....	C-2
C.2	Reading of Outputs (Read Coil Status) .....	C-2
C.3	Reading of Inputs (Read Input Status) .....	C-3
C.4	Reading of Metering Register (Read Input Registers).....	C-3
C.5	Commands (Force Single Coil).....	C-4

---



Documentation specific to the models with the MODBUS RTU communication profile

## C.1 Preliminary Information

This document is intended as a reference on the implementation of the MODBUS RTU Protocol in the **#CPI**.

This document describes the MODBUS map of addresses (inputs, outputs, metering registers and commands) and their equivalent in the **#CPI**.

The functions implemented are as follows:

ModBus Function	Description
01	Reading of Outputs (Read Coil Status)
02	Reading of Inputs (Read Input Status)
04	Reading of Metering Registers (Read Input Registers)
05	Commands (Force Single Coil)

*Any other function non-included in the table above will be considered illegal and the exception code 01 (Illegal function) will be returned as a reply.*

## C.2 Reading of Outputs (Read Coil Status)

- **Range of Modbus Addresses for the #CPI**

The Output Modbus addresses assigned to the **#CPI** are as follows:

Addresses	Description
0200H..02FFH	Outputs Status

- **Map of Modbus Addresses for the #CPI**

The Output Modbus addresses assigned to the **#CPI** are as follows:

Addresses	Description
0200H	AUX-1 Status
0201H	AUX-2 Status

Assigned addresses are fixed and their content is variable (it depends on the configuration selected by the end-user for each relay).

*The remaining addresses of the range will be considered as illegal and the exception code 02 (Illegal Data Address) will be returned as a reply.*



### C.3 Reading of Inputs (Read Input Status)

- **Range of Modbus Addresses for the #CPI**

The Input Modbus addresses assigned to the #CPI are as follows:

Addresses	Description
0000..00FFH	Inputs Stauts

- **Map of Modbus Addresses for the #CPI**

The Input Modbus addresses assigned to the #CPI are as follows:

Addresses	Description
0000H	INPUT-1 Status
0001H	INPUT-2 Status

Assigned addresses are fixed, their content being variable (it depends on the configuration selected by the end-user for each relay).

*The remaining addresses of the range will be considered as illegal and the exception code 02 (Illegal Data Address) will be returned as a reply.*

### C.4 Reading of Metering Register (Read Input Registers)

- **Range of Modbus Addresses for the #CPI**

The Modbus addresses for the Metering Input Registers assigned to the #CPI are as follows:

Addresses	Description
2000H..201FH	Metering Value

- **Map of Modbus Addresses for the #CPI**

The Modbus addresses for the Metering Input Registers assigned to the #CPI-A/B are as follows:

Addresses	Description
2000H	Phase A Overcurrent Metering
2001H	Phase B Overcurrent Metering
2002H	Phase C Overcurrent Metering

The Modbus addresses for the Metering Input Registers assigned to the #CPI-C are as follows:

Addresses	Description
2000H	Ground Overcurrent Metering

*The rest of addresses of the range will be considered as illegal and the exception code 02 (Illegal Data Address) will be returned as a reply.*



## C.5 Commands (Force Single Coil)

- Range of Modbus Addresses for the #CPI

The range of Modbus addresses for commands in the #CPI is as follows:

Addresses	Description
00200..02FFH	Commands

# D. Schemes and Drawings



---

## Dimension and Drill Hole Schemes

3CPI	>>4BF0100/0016
Adapter board to 19"x 2U / 8CPI	>>4BF0100/0026

## External Connection Schemes

CPI-A	>>3RX0131/0034 (Generic)
CPI-B	>>3RX0131/0035 (Generic)
CPI-C	>>3RX0131/0036 (Generic)

---



1

2


3

4

CAJA TIPO "D"  
ENCLOSURE TYPE "D"  
CAIXA TIPO "D"



A

A



B


B



TALADROS 5mm  
5mm DRILLING  
FUROS 5mm

C

C




TAPA  
FRONT COVER  
TAMPA

"ATENCIÓN"  
Este documento contiene información confidencial propiedad de ZIV. Cualquier forma de reproducción o divulgación está absolutamente prohibida y puede ser causa de severas medidas legales.

"ATENÇÃO"  
Este documento contém informação confidencial de propriedade de ZIV. Qualquer forma de reprodução ou divulgação está absolutamente proibida e sujeita a severas medidas legais.

"WARNING"  
This document contains trade secret information of ZIV. Unauthorized disclosure is strictly prohibited and may result in serious legal consequences.



ZIV Aplicaciones y Tecnología, S.L.

TÍTULO: DIMENSIONES Y TALADRADO

PROYECTO: CAJA TIPO "D" 6U 1/7RACK

Rev. 0  
Rev. 1 14/9/98  
Rev. 2 14/2/02

NÚMERO: 4BF0100/0016

D

D

REVISIONES	0	CDN9605104	1	CDR9809104
2	CD0202125	3	4	
5		6	7	
8		9	10	
11		12	13	
14		15	16	

	Fecha	Nombre	Hoja: 1 Continua en Hoja:
Dibujado	3/5/96	J.C.S.	
Aprobado	3/5/96	R.O.	

1

2

3

4

1

2

3

4

A


A

B

B

C

C



**"ATENCIÓN"**


Este documento contiene información confidencial propiedad de ZIV. Cualquier forma de reproducción o divulgación está absolutamente prohibida y puede ser causa de severas medidas legales.

**"ATENÇÃO"**

Este documento contém informação confidencial de propriedade de ZIV. Qualquer forma de reprodução ou divulgação está absolutamente proibida e sujeita a severas medidas legais.

**"WARNING"**

This document contains trade secret information of ZIV. Unauthorized disclosure is strictly prohibited and may result in serious legal consequences.



ZIV Aplicaciones y Tecnología, S.L.

**TÍTULO: PLACA ADAPTACION A 19" X 2U**

PROYECTO: RELE INDUSTRIAL

Rev. 0  
Rev. 14/2/02

**NÚMERO: 4BF0100/0026**

REVISIONES	0	CDN9904147	1	CD0202125
2	3		4	
5	6		7	
8	9		10	
11	12		13	
14	15		16	

	Fecha	Nombre	Hoja: 1
Dibujado	29/4/99	J.C.S.	Continua en Hoja:
Aprobado	29/4/99	R.O.	

1




2

3

4

D

D



Z I V Aplicaciones y Tecnologia S.A.

TITLE: EXTERNAL CONNECTIONS 3/8CPI-A

PROJECT: OVERCURRENT PROTECTION



Rev.0

NUMBER: 3RX0131/0034

**"WARNING"**  
This document contains trade secret information of Z I V S.A.  
Unauthorized disclosure is strictly prohibited and may result  
in serious legal consequences.

REVISIONS	0	CD0303176	1	2	3	4
	5	6	7	8	9	10
	11	12	13	14	15	16

	Date	Name	Sheet: 1
Drawn	15/04/03	J.C.S.	Continued on Sheed:
Approved	15/04/03	J.M.Y.	




TITLE: EXTERNAL CONNECTIONS 3/8CPI-B  
PROJECT: OVERCURRENT PROTECTION

Rev. 0	NUMBER: 3RX0131/0035		
Drawn	Date	Name	Sheet: 1
Approved	15/04/03	J.C.S.	Continued on Sheed:
	15/04/03	J.M.Y.	

**"WARNING"**  
This document contains trade secret information of Z I V S.A.  
Unauthorized disclosure is strictly prohibited and may result  
in serious legal consequences.

REVISIONS	0	CD0303176	1	2	3	4
5	6	7	8	9	10	
11	12	13	14	15	16	



**"WARNING"**  
 This document contains trade secret information of Z I V S.A.  
 Unauthorized disclosure is strictly prohibited and may result  
 in serious legal consequences.

REVISIONS	0	CD0303176	1	2	3	4
	5	6	7	8	9	10
	11	12	13	14	15	16

Z I V Aplicaciones y Tecnologia S.A.

**TITLE:** EXTERNAL CONNECTIONS 3/8CPI-C

**PROJECT:** OVERCURRENT PROTECTION

**Rev.0**

**NUMBER:** 3RX0131/0036

	<b>Date</b>	<b>Name</b>	Sheet: 1
<b>Drawn</b>	15/04/03	J.C.S.	Continued on Sheed:
<b>Approved</b>	15/04/03	J.M.Y.	



# E. List of Illustrations and Tables



---

E.1	List of Figures .....	E-2
E.2	List of Tables.....	E-2

---



## E.1 List of Figures

<b>4.</b>	<b>Physical Architecture</b>	
4.1	3CPI Front View.....	4-2
4.2	8CPI Front View.....	4-2
4.3	8CPI Rear View.....	4-3
4.4	3CPI Rear View.....	4-3
<b>5.</b>	<b>Settings</b>	
5.1	Internal Jumpers.....	5-4
<b>6.</b>	<b>Description of Operation</b>	
6.1	Inverse Time/Current Characteristic.....	6-3
6.2	Very Inverse Time/Current Characteristic.....	6-4
6.3	Extremely Inverse Time/Current Characteristic.....	6-5
6.4	Overcurrent Unit Block Diagram.....	6-6
6.5	Auxiliary Contact Output Logic Cell Block Diagram.....	6-11
6.6	LED Target Output Logic Cell Block Diagram.....	6-13
<b>7.</b>	<b>Alphanumeric Display and Keypad</b>	
7.1	Alphanumeric Display.....	7-2
7.2	Keypad.....	7-2
7.3	General Screen Sequence using the ↓ Key (with Trip Indication).....	7-4
7.4	General Screen Sequence using the ↓ Key (without Trip Indication).....	7-4
7.5	Metering Elements and Trip Information Screen Sequence. #CPI-A Model.....	7-5
7.6	Metering Elements and Trip Information Screen Sequence. #CPI-B Model.....	7-5
7.7	Metering Elements and Trip Information Screen Sequence. #CPI-C Model.....	7-5
<b>8.</b>	<b>Receiving Tests</b>	
8.1	Operating Time Test Setup.....	8-4

## E.2 List of Tables

<b>6.</b>	<b>Description of Operation</b>	
6-1	Events.....	6-7
6-2	Status Contact Inputs.....	6-10
6-3	Auxiliary Contact Outputs.....	6-12
<b>8.</b>	<b>Receiving Tests</b>	
8-1	Insulation Test (Transverse Mode).....	8-3
8-2	Current Measuring Test.....	8-4
8-3	Phase and Ground Units Test.....	8-4

## F. Warranty



---

---



### ZIV GRID AUTOMATION, S.L. Standard Product Warranty

All new products sold to customers are warranted against defects in design, materials, and workmanship for a period of ten (10) years from the time of delivery (at the moment the product leaves ZIV GRID AUTOMATION premises, as indicated in the shipping documents). Customer is responsible of notifying ZIV GRID AUTOMATION of any faulty conditions as soon as they are detected. If it is determined that the new product defect is covered by the warranty, ZIV GRID AUTOMATION will repair, or substitute the product at its own discretion to the customer at no charge.

ZIV GRID AUTOMATION may, at its own discretion, require the customer to ship the unit back to the factory for diagnosis before making a determination as to whether it is covered by this warranty. Shipping costs to the ZIV GRID AUTOMATION factory (including but not limited to, freight, insurance, customs fees and taxes, and any other expenses) will be the responsibility of the customer. All expenses related to the shipment of the repaired or replacement units back to the customer will be borne by ZIV GRID AUTOMATION.

Customers are responsible for all expenses related to the shipment of defective units back to ZIV GRID AUTOMATION when it is determined that such units are not covered under this warranty or that the fault is not ZIV GRID AUTOMATION's responsibility. Units repaired by ZIV GRID AUTOMATION are warranted against defects in materials, and manufacturing for a period of one (1) year from the time of delivery (at the moment the product leaves ZIV GRID AUTOMATION premises, as indicated by the shipping documents), or for the remaining of the original warranty, whichever is greater.

ZIV GRID AUTOMATION warranty does not cover: 1) improper installation, connection, operation, maintenance, and/or storage, 2) minor defects not interfering with the operation of the product, possible indemnities, misuse or improper usage, 3) abnormal or unusual operating conditions or application outside the specifications for the product, 4) application in any way different from that for which the products were designed, 5) repairs or alterations performed by individuals other than ZIV GRID AUTOMATION employees or an authorised representative.

#### Limitations:

- 1) Equipment or products provided but not manufactured by ZIV GRID AUTOMATION. Such products may be covered by a warranty issued by the corresponding manufacturer.
- 2) Software: ZIV GRID AUTOMATION warrants that the licensed Software corresponds with the specifications included in the instruction manuals provided with the units, or with the specifications agreed with the end-customer. ZIV GRID AUTOMATION sole and entire liability, and customer exclusive remedy, with respect to any claims relating to the Software shall be to provide a new set of diskettes free of charge.
- 3) In the case that a bank guarantee or similar instrument be required to back up the warranty period, such warranty period, and only for these purposes, will be of a maximum of twelve (12) months from the time of delivery (at the moment the product leaves ZIV GRID AUTOMATION premises, as indicated in the shipping documents).

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTIES AND ZIV GRID AUTOMATION HEREBY DISCLAIMS ANY OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ZIV GRID AUTOMATION BE LIABLE FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES OR FOR ANY OTHER LOSS, INJURY, DAMAGE, OR EXPENSE OF ANY KIND INCLUDING LOST PROFITS OR ANY OTHER PECUNIARY LOSS ARISING FROM ANY SOURCE.

ZIV GRID AUTOMATION, S.L.  
Parque Tecnológico, 210  
48170 Zamudio - Bizkaia - Spain  
Tel.- (+34)-(94) 452.20.03  
Fax - (+34)-(94) 452.21.40